





<http://www.yoursimdialer.com/>

Ykep Inc. Mobile Sim Dialers

-----Specification of Model BB10



What is it ?

A sim dialer is a mobile device to assist in easy dialing for you VOIP, SiP and/or calling card systems. A sim dialer will work with GSM or WCDMA network.

When end users make a call using a sim dialer, there is no need to dial the IP access number or the long destination numbers, as the sim dialer will auto dial these functions for you. The auto dialer can be set to auto distinguish which numbers go to VOIP system, which ones go through the original GSM or WCDMA network. Sim dialers are compatible with 95% of cell phone models in the world.

Features

1. The BB10 sim dialer has been tested on with GSM/ UMTS /3G SIM card /**prepaid calling card**.
2. This is the slim version with large memory chip(**32KB**), which requires the SIM CARD to be cut, Ykep has designed a customized sim card cutter, which makes it easy to cut the GSM Sim Card, and after cutting, insert into any sim slot slot.
3. High quality FPC board, strong flexibility allows for 5 year stable usage.
4. Can store **5** groups of IP access number, but you can only use one in one time.
5. Support **40** groups of bypass numbers.
6. Will auto distinguish which numbers to switch to **VOIP system**, which ones To switch to **original** GSM or WCDMA network.
7. Support callback, callthrough, calldirect systems.
8. No need to manually input **PIN code**.
9. Stored services' hotline, users call center only by pressing one button.
10. Auto realize the SIM card from which countries and which carriers depending on the **MCC**(mobile country code) and **MIC**(mobile network code),and choose the corresponding IP access numbers.
11. Compatible with Nokia, Motorola, iphone, blackberry, Sony Ericsson, Samsung, LG... Etc

Ykep, Inc

TEL: 1-866-722-7024

Fax:1-888-250-8341

your_sim_dialer@sbcglobal.net



<http://www.yoursimdialer.com/>

Large memory of the IC chip, allows for many more additional functions.


How to assemble?

You need to punch the SIM Card with the special cutter, and then place on top of the the sim dialer, then insert them into the card slot together. When you turn on your mobile, you will see

The **Mobile Dialer** displayed on the screen - we can change the **Mobile Dialer** to your **company name**.



You can choose the packaging style



120*62*2 mm

70*60.5*0.91 mm 30*25*4 mm

We can customize the following for you:

- ▶ Pre-configure access number,
- ▶ Changing pass code.
- ▶ Showing your brand name on the standby-screen.
- ▶ Label your brand name on the PCB Board.
- ▶ Customized packaging.
- ▶ Revised the software.



<http://www.yoursimdialer.com/>

Guarantee policy:

- ▶ We can offer free replacement within one year except for broken dialers.

Delivery time:

- ▶ Delivery with 7 work days after receiving payment.
- Orders are shipped via USPS, which takes 5 to 7 days to deliver.

Frequently Asked Questions:

- 1). Can the sim dialer be used for all brand mobile phones and for all networks?
The SIM dialer will work with GSM /UMTS/USIM/UICC/WCDMA SIM card
At present the BB10 works with 99% of mobile phones.
- 2). After installing the Mobile Dialer, I can't connect and use the Calling Card Service.
 - A). Make sure that you have correctly assembled the SIM CARD and sim dialer.
 - B). Confirm you have turned on the sim dialer.
 - C). Confirm that your provider's service covers your area.
- 3). After installing the sim dialer, will all the numbers go through VOIP system?
You can pre-set which numbers you want to through VOIP system or not; e.g. toll Free, local or emergency numbers. This setting is done in **Bypass Prefixes**
- 4). Does the SIM dialer support PIN system?
Yes, you can pre-set as following:
Mobile Dialer-->PIN code-->
For normal PIN, you can only input digits here, but for calling card, you need to add plus# at the end.
If there are several PIN codes, use + to separate them. Like: 3+4050587#
- 5). I have several calling cards, can I use them freely?
Yes. The BB10 SIM dialer will support 5 access numbers, you can preset them on Different service number, plus the BB10 sim dialer will auto detect which access number to use while roaming.
- 6). Can I use callback and callthrough simultaneity?
The BB09 and BB10 allows for this function.



<http://www.yoursimdialer.com/>

7) Can I change the password by myself?

Yes, you can re-configure the password by yourself, it's only allow to input 4digits
Mobile Dialer-->Setting (default password is 000000)-->Change Password

8) For some 3G phone, it could not find the SIM dialer menu, how can I do?

You can program the dialer in 2G phone firstly, and then insert to 3G phone, or configure
It on PC firstly, or use the SMS function.